


































2014 Gadget Menagerie – Washington State Library

Device/model name	Kindle	Kindle Fire HD	Nook HD+	Nook Simple Touch	Galaxy Note Tab 10.1	iPad	Surface RT	Chromebook	Arc 7	Nexus 7	Transformer Pad (TF701T)
Manufacturer	Amazon	Amazon	Barnes & Noble	Barnes & Noble	Samsung	Apple	Microsoft	Acer	Kobo	Google	Asus
Operating System 	Fire OS 3.0 (Android "Mojito") 	Android 4.0 (Ice Cream Sandwich)  	Android 4.3 (Honeycomb) 	iOS 	Microsoft Windows RT 8 	Chrome OS 	Android 4.2.2 (Jelly Bean) 	Android 4.3 (KitKat) 	Android 4.3 
eBook/Textual file types	Kindle Format 8 (AZW3), Kindle (AZW), TXT, PDF, unprotected MOBI, PRC natively; HTML, DOC, DOCX, JPEG, GIF, PNG, BMP through conversion	Kindle (AZW), KF8, TXT, PDF, unprotected MOBI, PRC natively, Audible Enhanced format (AAX), DOC, DOCX	PDF, ePub, DRP, ePIB, FOLIO, OFIP, CBZ, TXT, RTF, XLS, DOC, PPT, PPS, PPSX, DOCX, XLSX, PPTX, LOG, CSV, EML, ZIP	ePub, PDF	all (more or less)	ePub, PDF (using eBooks app)	Windows Office Suite, PDF, etc.	PDF, Google Docs, Windows Office Suite (requires conversion to Google Docs)	all (more or less)	all (more or less)	all (more or less)
App/Content Store or Portal	Kindle Store 	Kindle Store 	Nook  Google Play	Nook  "Shop"	Google Play 	Apple App Store 	Windows Store 	Chrome Web Store 	Google Play 	Google Play 	Google Play 
Interface	(E-Ink) Condensed Keyboard	Touchscreen	Touchscreen	(E-Ink) Touchscreen	Touchscreen	Touchscreen	Touchscreen	Traditional Keyboard	Touchscreen	Touchscreen	Touchscreen
Connectivity options	Wi-Fi	Wi-Fi / cellular on certain models	Wi-Fi	Wi-Fi	Wi-Fi and cellular	Wi-Fi / cellular on certain models	Wi-Fi	Wi-Fi / cellular on certain models	Wi-Fi	Wi-Fi / cellular on certain models	Wi-Fi
Power button				(on back) 				(Acer Chromebook only) 			

Quick start guides for selected gadgets:

Nook SimpleTouch: http://img1.imagesbn.com/PIimages/nook/2/mediakit/quickstartguide_nooksimpletouch_111229.pdf

Nook HD+: <http://img1.imagesbn.com/pImages/nook/nook07/mediakit/Quick Start Guide NOOK HD Plus v3.pdf>

Kindle: <http://kindle.s3.amazonaws.com/KindleQuickStartGuide.pdf>

Kindle Fire HD: http://kindle-fire-updates.s3.amazonaws.com/Kindle_Fire_HD_Quick_Start_Guide.pdf

Note: The Kindle User's Guide is available on-device:

1. On your Kindle Fire, swipe down from the top of the screen and tap **More**.
2. Tap **Help & Feedback**, and then tap **User Guide**.

Samsung Galaxy Note 10.1: http://downloadcenter.samsung.com/content/UM/201208/20120821042319330/GT-N8013_English_User_Manual_LGB_F3.pdf

iPad and iPad Mini: http://manuals.info.apple.com/MANUALS/1000/MA1595/en_US/ipad_user_guide.pdf

Microsoft Surface RT: http://download.microsoft.com/download/B/D/4/BD44C612-D08E-4586-9345-ACA8AB978BC8/en-us_Surface_RT_User_Guide.pdf

Acer Chromebook: http://global-download.acer.com/GDFiles/Document/QuickStartGuide/QuickStartGuide_Acer_01.01.02_A_A.pdf?acerid=634937436010562109&Step1=NETBOOK,%20CHROMEBOOK&Step2=CHROMEBOOK&Step3=C710&OS=ALL&LC=en&BC=ACER&SC=PA_6

Kobo Arc 7: http://download.kobobooks.com/magento/userguides/downloads/KoboArc7/koboarc7_userguide_en.pdf

Google Nexus 7: https://static.googleusercontent.com/media/www.google.com/en/us/help/hc/images/android/android_ug_42/Android-Quick-Start-Guide.pdf

Asus Transformer Pad: http://dlcdnet.asus.com/pub/ASUS/EeePAD/TF701T/e8803_tf701t_em_v2_for_web_only.pdf