

How to Use a Kindle

1. After opening the front cover, the message on the screen reads: *Slide and release the power switch to wake.* The switch is located directly below the **Home** button on the lower right front edge of the Kindle.
2. If necessary, press the **Home** button to display a list of book titles.
3. Use the arrow keys located below the **Menu** button to move the cursor and make your selection. Press the **Enter / Select** button in the center of the arrow keys to open your book.
4. You will notice two other sets of arrow keys. At first, you will be working with the keys located in the keyboard area. After you have made your reading selection, use the **Previous Page** and **Next Page** keys located on either side of the Kindle to turn pages.
5. Need the ISBN number or other bibliographic information? First, select the story. It will display at the first page of chapter one. From there, use the **Previous Page** arrow on either side of the Kindle to find the bibliographic information, book jacket information, title page, or table of contents.
6. Use the **Menu>Go To...** feature to reset your Kindle to the beginning of a book or move between chapters.
7. To enlarge the font, change the line spacing, set the number of words per line, or to use the Kindle as an audio book: First, select your story. Open it, and then click on the **AA** button (it's to the left of the **Home** button). A new box appears. Use the **Move Cursor** arrows to scroll down and make your selection, then push the **Enter / Select** button.
8. If you have walked away and the screen saver is on, just *slide and release the power switch to wake* and the Kindle will display where you left off.
9. More detailed instructions can be found in the "Kindle User's Guide" located among the list of books.

